∆WARNING:

- Do not allow children to play in water that is near an electrical source or apparatus in order to avoid electric shock and/or electrocution.
- Do not leave puppy near an electrical source or apparatus when wet.
- Do not use the Swim to Me Puppy™ as a flotation device.
- · Always supervise when children are playing around water.

IMPORTANT INFORMATION

- Switch from the ON (1) position to the OFF (0) position after playing to conserve battery power.
- Avoid leaving puppy in extremely hot or extremely cold water.
- Avoid keeping puppy in bath, salt or chlorinated pool water, as discoloration or bleaching may occur.
- Only place puppy in clean, clear water.
- After play, drain excess water from the holes on puppy's back. Air dry the puppy thoroughly and bring indoors. Prolonged exposure to sunlight will cause damage to the puppy.
- Wipe clean with a damp cloth.
- Only place puppy's body into the water. Don't immerse completely in water.
- Do not place puppy's leash around people or animals' necks. Only use in the manner described in this manual.
- Avoid putting puppy's leash in water.
- If water gets into the battery compartment, remove the batteries immediately and let the open compartment air dry.

BATTERY SAFETY INFORMATION

- Use only size "AAA" (LR03) alkaline batteries (3 required).
- · Charging of rechargeable batteries should only be done under adult supervision with batteries removed from product.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instruction.
- Always remove exhausted or dead batteries from the product.
- Dispose of dead batteries properly: do not burn or bury them.
- Do not attempt to recharge non-rechargeable batteries.
- Avoid short-circuiting battery terminals.
- Remove batteries before placing the unit into storage for a prolonged period of time.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



1-800-321-0183

The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



© The Little Tikes Company, an MGA Entertainment company. the U.S. and other countries. All logos, names, characters, likenesses, images slogger and an incident shadow. likenesses, images, slogans, and packaging appearance are the Milton Keynes property of Little Tikes. Little Tikes Consumer Service 2180 Barlow Road Hudson, Ohio 44236 U.S.A.

50 Presley Way Crownhill MK8 0ES Bucks, UK 0800 521 558

MGA Entertainment UK Ltd

www.littletikes.com www.littletikes.co.uk



Visit our website at www.littletikes.com to register your product and to enter our sweepstakes. (No purchase necessary)





SWIM TO MO PUPRY

AGES 3+ YEARS ADULT SUPERVISION AND BATTERY INSTALLATION REQUIRED.

CONTENTS

- A. 1 Swim to Me Puppy™
- B. 1 Pair of Goggles
- C. 1 Adoption Certificate
- D. 1 Leash







C. official Aboption

Illustrations are for reference only. Styles may vary from actual contents.

BATTERY INSTALLATION


Before playing with Swim to Me Puppy™, an adult must install fresh alkaline batteries. Here's how:

- 1. Using a Phillips screwdriver (not included) remove the screws and battery compartment cover
- from the underside of the puppy.

 2. Install three (3) fresh 1.5V AAA alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
- 3. Replace the compartment cover and tighten the screws.

IMPORTANT NOTES:

- Dry the puppy thoroughly before opening the battery compartment.
- If moisture is present in the battery compartment, dry it with a towel.




0518-0-E/INT Printed in China

OUICK START

Before beginning, cover the play area to prevent possible water damage.


GETTING STARTED

Turn on your puppy by moving the switch under the collar from the OFF (**0**) position to the ON (**1**) position.




SWIMMING WITH YOUR PUPPY


 \triangle CAUTION: Adult supervision is required when children are playing around water.




Place goggles over the puppy's head.



With the puppy's head facing forward, set it in a bathtub, swimming pool or other large container of clean, clear water. For best results, hold the puppy's body under water until all of the air bubbles disappear from the openings on its back.



As soon as the puppy's sensors touch the water, it begins to kick its legs and swim straight ahead. Sensors are located under the tail.




Remove puppy from the water and his legs will stop moving. If legs don't stop kicking, see page 3.

WALKING YOUR PUPPY




Move the switch from the OFF (**O**) position to the ON (**I**) position as seen on page 2. Then, place leash around puppy's neck.




To get puppy to walk, press on the collar's tag. To turn off puppy, press its tag again.

TURNING YOUR PUPPY OFF


If the puppy's legs don't stop kicking after removing from the water, try the below steps.



Remove the puppy from the water and locate the sensors under the tail.



Using a towel or dry cloth, wipe off any moisture on the sensors. The puppy's legs will stop moving.



If drying the sensors doesn't work, move the switch from the ON (\mathbf{I}) position to the OFF (\mathbf{O}) position.