

IMPORTANT INFORMATION

- ADULT ASSEMBLY REQUIRED.
- Always turn the unit OFF (O) after use to conserve battery power.
- Keep long hair and other loose objects, like shoelaces, away from the rotating tires of the **engine**.
- DO NOT launch **the engine** at people or pets.
- Only use included obstacles as other items may be damaged by **engine** impact.
- Frequently clean the tires on the **engine** with a damp cloth to remove debris and optimize performance.
- Keep water away from the battery compartment.

BATTERY SAFETY INFORMATION

- Use only size "AA" (LR6) alkaline batteries (2 required).
- Charging of rechargeable batteries should only be done under adult supervision.
- Remove rechargeable batteries from the product before recharging.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instruction.
- Always remove exhausted or dead batteries from the product.
- Dispose of dead batteries properly: do not burn or bury them.
- Do not attempt to recharge non-rechargeable batteries.
- Avoid short-circuiting battery terminals.
- Remove batteries before placing the unit into storage for a prolonged period of time.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.

CAN ICES-3 (B)/NMB-3(B).



'Let's care for the environment!'

The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



Printed in China
0319-0-E/INT

© The Little Tikes Company, an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.



www.littletikes.com
www.littletikes.co.uk

Little Tikes Consumer Service
2180 Barlow Road
Hudson, Ohio 44236 U.S.A.
1-800-321-0183

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill, Milton Keynes,
MK8 0ES, Bucks, UK
+ 0800 521 558

MGA Entertainment (Netherlands) B.V.
Klipperaak 201, 2411 ND Bodegraven, NL
Tel.: +31 (0) 172-758 038
E-mail: klantenservice@mgae.com

Imported by MGA Entertainment Australia Pty Ltd
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113
1300 059 676



Runaway Railroad™

SKU: 649516

AGES 3+ YEARS

ADULT SUPERVISION RECOMMENDED

ADULT ASSEMBLY AND BATTERY


INSTALLATION REQUIRED

CONTENTS

A. 1 Tunnel
B. 1 Water Tower
C. 1 Rock Cave
D. 1 Mudslide Curve
E. 2 Small Fences

F. 2 Large Fences
G. 1 Exclusive Slammin' Racers™ Engine
H1. Train Car 1
H2. Train Car 2

I. 1 Boulder
J. 2 Crates
K. 3 Balls
L. 2 Bank Turns
M. 1 Cave Turn




Illustrations are for reference only. Styles may vary from actual contents.

BATTERY REPLACEMENT INFORMATION

The batteries included in the **engine** are for in-store demonstration. Before playing, an adult must install fresh alkaline batteries (not included) in the unit. Here's how:


1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the under the **engine**.
2. Install two (2) 1.5V AA (LR6) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.




ASSEMBLY




Please follow instructions carefully.
Once assembled, some parts may not be removed.



Snap the water tower onto the tunnel.
Then, load the balls into the tower.



Snap the rock cave onto the cave turn,
and place the boulder on top.




Snap the large fences onto the outside of the turns.
Snap the small fences onto the inside of the turns.



Connect the train cars to the engine and
load them up with crates or balls!


CONFIGURATION

Set railroad parts close together or far apart to test your slammin' skills!
Can you make it all the way through the track?
How many other configurations can you create?



FEATURES


For best results use on a hard, flat surface in an open area.




Turn the **engine ON (I)**. It will make engine sound effects.




Slam the button on the engine to watch it go and hear driving sounds! Slam the button while the **engine** is driving to for special boost sound effects and extra distance!




Open the cover on the water tower to release the balls
onto the engine as it passes by.



When the **engine** passes through the rock cave,
the boulder will **fall down**.



Set the gates in the wide position for easy entrance.



Move the gates inward to make your exit path narrow
and help direct the engine to the next turn.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.