


ASSEMBLY INSTRUCTIONS



Thank you for choosing the Little Tikes® Learn & Play™ Roll Arounds™ Turnin' Town.
We strive to provide a durable, easy-to-assemble toy that is made to last,
giving your child years of imaginative, engaging fun!

⚠ **CAUTION:** This toy is not a ball and should not be thrown at people, pets or other objects.

IMPORTANT INFORMATION YOU SHOULD KNOW!

- Read through all the instructions first.
- Clear a flat surface to lay out all the materials so that everything is close at hand.
- Illustrations are for reference only. Styles may vary from actual contents.
- Please remove all packaging including tags, ties & tacking stitches before giving this product to a child.
- **Make sure you have all contents before assembling. If anything is missing or if you have questions, we're here to help. Give our consumer service team a call at 1-800-321-0183.**

Let's be careful!

⚠ WARNING!

- ADULT ASSEMBLY REQUIRED.
- Prior to and during assembly, keep away from children until assembled.
- Follow the provided instructions to avoid potential hazards that may result from incorrect assembly.
- Please keep this manual as it contains important information.
- This product is intended for indoor use only.
- This product is intended for use by children 18+ months.
- Do not allow children to stand or sit on the unit.
- Place on flat, level surfaces free of objects that could cause the toy to tip over. Also, place out of the way of household traffic.
- Never use near staircase, steps, pools, hot surfaces, or areas that may be hazardous to a child.
- Do not use if damaged, broken or if components are missing.
- Clean with a cold damp cloth and wipe off any moisture with a dry cloth.
- Do not play with vehicle in the street, where there is vehicular traffic or in heavily traveled areas with pedestrians.
- Do not roll the vehicle into furniture, walls, pets, people, etc., as doing so may cause injury to the person and irreparable damage to the unit.
- Do not roll through water, mud, etc.
- Keep long hair and other loose objects, like shoelaces, away from the rotating roller under the vehicle.
- Hold the vehicle tightly to avoid accidentally dropping it on your feet.
- Keep vehicle away from mouth.

IMPORTANT: Retain these instructions for future reference.

© The Little Tikes Company, an MGA Entertainment company. LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.

Printed in China • 0821-0-EUC

CONSUMER SERVICE

Little Tikes Consumer Service
www.littletikes.com
 2180 Barlow Road
 Hudson, Ohio 44236 U.S.A.
 Email: service@littletikescares.com
 1-800-321-0183 Monday-Friday

MGA Entertainment UK Ltd.
www.littletikes.co.uk
 50 Presley Way, Crownhill, Milton
 Keynes, MK8 0ES, Bucks, UK
support@LittleTikesStore.co.uk
 Tel: +0 800 521 558

Imported by MGA Entertainment Australia Pty Ltd
www.littletikes.com.au
 Suite 2.02, 32 Delhi Road
 Macquarie Park NSW 2113
 1300 059 676




LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers.
U.S.A. and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details.
Outside U.S.A. and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

13

Time to Play!


Before beginning, move the switch on the Base from the OFF (O) position to low or high volume. Place the Car on the plate on top of Track 1 (O). Press down the lever and watch the Car roll down the spiral. When the Car hits the Track Door (R), gently spin the handle on the Wheel (B) to continue moving the Car through the tracks. Avoid spinning the handle too fast or the car will fall off the wheel.



14

Many Different Ways to Play!


Your Turnin' Town has so many different pathways. See below the different ways your Cars can go.



Whenever the Vehicle hits one of triggers on the Base, it will make different sounds.

BONUS!


The top of the tower has two pathways. Insert the Car to see which path it will take.



11

Add the Finishing Touches to the Wheel


Insert the Track Door (R) to Track 3 (Q). Note that one peg is bigger than the other for correct placement. Then, attach the tab on Small Track (T) to the slot in the Right Town Tower - Middle (G).



12

Move On to the Other Side

Insert the tabs on the Top Track (U), Middle Track (V) and Bottom Track (W) into the tabs on the back of the towers.



Battery Safety Information. This is serious!

- Keep these instructions for future reference.
 - Requires 3 "AA" (LR6) alkaline batteries (not included). (Rechargeable batteries may be substituted.)
 - The voltage of a fully-charged, rechargeable battery is often lower than that of a fresh alkaline battery. Therefore, it is recommended that alkaline batteries be used instead of rechargeable batteries for best performance and longer play time.
 - Install batteries with the correct polarity (+ and -).
 - To avoid battery leakage:
 1. Follow the toy and battery manufacturer's installation instructions.
 2. Do not mix old and new batteries.
 3. Do not mix standard (carbon-zinc), alkaline or rechargeable batteries. Do not mix different brands of batteries. Only batteries of the same or equivalent type as recommended are to be used.
 4. When toy is not used for an extended period of time, remove batteries to prevent possible leakage and damage to the unit.
 5. Remove dead or exhausted batteries from product.
 6. Dispose of dead batteries properly; do not bury. Do not dispose of batteries in fire as they may leak or explode.
 - Make sure cover is properly installed on unit at all times.
 - Do not attempt to recharge non-rechargeable batteries.
 - Rechargeable batteries are to be removed from the toy before recharging.
 - Charging of rechargeable batteries should be done by an adult.
 - The supply terminals are not to be short circuited.
 - Always turn the unit off after playing to conserve battery power.
- NOTE:** If the unit stops working or doesn't work as it should, remove the batteries for a few minutes and then re-insert them. If there is still a problem, install new batteries

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic

Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1)

This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3 (B)/NMB-3(B).



'Let's care for the environment!'

The wheeled bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.


A Few Things Before You Start!

BEFORE you begin assembly, make sure you have all the parts listed below.
Questions? We're here to help. Little Tikes® Consumer Service: 1-800-321-0183

IMPORTANT TIP: Before assembling, wipe off any residue on the tracks using a clean, dry cloth.
This will help the cars roll smoothly on the tracks.


Town Parts

IMPORTANT NOTE: Some parts have letters and others have a letter with number for correct assembly.
When assembling the Turnin' Town, make sure to match the letters or letters with numbers.




9 Insert the Slide

Place the Slide (S) into the Base (A).




10 Insert the Wheel

Place the Wheel (B) into the Base (A).




7 Connect the Next Town Tower Part and Track 2

Attach Town Tower - 2nd Top (M) to the Middle Town Tower (L), making sure the "N1's" and "N2's" match. Place Track 2 (P) into the slots on the Middle Town Tower. The "I's" should match. Then, connect the Tracks by matching the "L's."



8 Finish the Top of the Town Tower


Place Track 1 (O) into the slots on the 2nd Top (M). Then, connect the Tracks by matching the "J's". Finish the tower by attaching Town Tower - Top (N).



Before you begin, install the batteries!


Before beginning, an adult must install fresh alkaline batteries. Here's how:

1. Using a Phillips screwdriver (not included), remove the screw and battery compartment cover located under the Base (A).
2. Install three (3) fresh 1.5V AA (LR6) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.




1 Minor Pre-Assembly

Connect Town Tower -2nd Bottom (K) to the top of Town Tower - Bottom (J), making sure the "T1's" and "T2's" match.



2 Start from the Bottom

Insert the Right Town Tower Bottom (F) and the pre-assembled Town Tower - Bottom (J) into Base (A). Finally, insert Left Town Tower - Bottom (C) into the Base.




WAIT!

For correct placement, match the letter with number on the base with the letter/number on the sides of the bottom towers.


3 Work Your Way Up

Attach the Town Tower - Middle (L) to the 2nd Bottom (K). The "P1's" should match.




4 Finish the Left Town Tower

Attach Left Town Tower - Middle (D) to the top of Left Town Tower - Bottom (C). Then, finish the left tower by attaching the Left Town Tower - Top (E).



5 Finish the Right Town Tower and Add the Front Town Tower

Attach Right Town Tower - Middle (G) to the top of Right Town Tower - Bottom (F). Then, attach the Right Town Tower - Top (H) to finish the tower. Finally, insert the Front Town Tower (I) into the Base.



6 Add Track M

Place Track 3 (Q) over the Town Tower (L), making sure the "M" tab on the track matches with the "M" slot on the tower. Then, insert the two poles under Track 3 into the slots on top of Left Town Tower (E) and Right Town Tower (H).

