


BATTERY REPLACEMENT:

The batteries included in the unit are for in-store demonstration. Before beginning, an adult must install fresh alkaline batteries. Here's how:

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the back side of the device.
2. Install three (3) 1.5V AAA (LR3) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.



BATTERY SAFETY INFORMATION:

- Keep these instructions for future reference.
- Use only size "AAA" (LR3) alkaline batteries (3 required).
- Charging of rechargeable batteries should only be done under adult supervision but with batteries removed from product.vv
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instruction.
- Always remove exhausted or dead batteries from the product.
- Dispose of dead batteries properly: do not burn or bury them.
- Do not attempt to recharge non-rechargeable batteries.
- Avoid short-circuiting battery terminals.
- Remove batteries before placing the unit into storage for a prolonged period of time.
- To prolong the life and operation of the unit, bring the unit indoors during inclement weather conditions.

NOTE: If the unit stops working or doesn't work as it should, remove the batteries for a few minutes and then re-insert them. If there is still a problem, instal new batteries.

IMPORTANT INFORMATION:

- Do not expose the unit to moisture of any kind. Wipe the unit with a damp cloth to clean.
- Do not use the product if it is damaged or broken.
- Use only on flat, level surfaces free of objects.
- Never use near steps, pools, hot surfaces, or areas that may be hazardous to a child.
- If the unit stops working properly or doesn't work as it should, turn off and turn it back on. If there is still a problem, replace the batteries.

